

GTM400 SERIES

400 AMP 1500 VDC HERMETIC SEALED DC CONTACTOR



Features

- Small, compact contactor for switching 1500 Vdc
- UL and CE recognition planned
- · Fully Bidirectional switching
- Hermetic Seal Exceeds IP67-69 specifications No exposed arcing to open air environments
- Perfect for solar, photovoltaic, inverter systems, battery packs, combiner boxes, DC arc fault interrupter systems or any
- other high voltage DC system
- High Efficiency DC Coils PWM and dual coil. Ideal for systems where low coil power consumption is required
- Upright (Stand-up) mounting, Side mounting housing in process. Custom harnesses available
- · Aux switch SPDT (Normally Open, Normally Closed or both)



SPECIFICATIONS

		Units	Data	
Rated Voltage		V	100	
Contact Arrangement	Main	Form X	SPST-NO	
	Auxilary (3A, 24VDC) ⁹	Form A or B	SPDT or SPST	
Mechanical Life		Cycles	1,000,000	
Contact Resistance ¹	Max	mohms	0.4	
	Typical	mohms	0.15 to 0.2	
Operate Time ²	Max	ms	40	
	Typical	ms	20	
Release Time, Max		ms	12	
Insulation Resistance ³		Mohms	100	
Dielectric At Sea Level (Leakage < 1mA)		VRMS	5,400	
Shock, 1/2 Sine, 11ms		G	35	
Vibration, Sinusoidal (500-2000 Hz Peak)		G	20	
Ambient Temp Range	Operating ⁴	°C	-40 to +85	
	Storage	°C	-70 to +150	
Weight, Typical		Kg (Lb)	<0.91 (2.0)	
Environmental Seal		Exceeds IP67 & IP69K		
Salt Fog		MIL-STD-810		






COIL RATINGS AT 25°C

Coil P/N Designation	В	C	F	M (PWM)
Coil Voltage, Nominal	12 VDC	24 VDC	48 VDC	12/24 VDC
Coil Voltage, Max	16 V	32 V	60 V	36 V
Pick-Up Voltage, Max ^{5, 7}	8 V	16 V	40 V	8.5 V
Drop-Out Voltage	0.5 to 4 V	2 to 7.5 V	4 to 15 V	6.5 V
Pick-Up Current, Max (75 ms) ^{6, 7}	4.3 A	1.6 A	0.98 A	3.6 A
Coil Current ⁶	0.24 A	0.09 A	0.044 A	0.13 A (12) 0.07 A (24)
Coil Power ⁶	2.9 W	2.1 W	2.1 W	1.7 W
Internal Coil Suppression				
Coil Back EMF	55 V	55 V	125 V	0 V
Transients, Max (13 ms)	±50 V	±50 V	±75 V	±60 V
Reverse Polarity	16 V	32 V	64 V	100 V

0


DC POWER SWITCHING CYCLES⁸






CURRENT CARRY

with 85°C terminal temperature rise 400A 400MCM or greater



Example: GTM400BAB





GENERAL NOTES

- Contact resisitance measured at currents higher than 100A.
- 2. Operation time is measured at 25°C and includes maximum 7ms bounce.
- Insulation resistance is 50 Mohms after life.
- 4. Contactor can operate up to 125°C in special cases contact Sensata for details.
- 5. Contactor has two coils. Both are used for pick-up, and then in approximately 75 milliseconds, one coil is electronically removed from the coil drive circuit. The remaining coil supplies low continuous hold power sufficient for the contactor to meet all of its specified performance specifications. This provides low coil power without PWM electronics that can cause EMI emissions and/or cross-talk on control power.
- 6. Contactor is operated by a coil that changes resistance with temperature. Since pick-up current, coil current and coil power are specified at nominal voltage, they will be lower than indicated at temperatures above 25°C and higher than indicated at temperatures below 25°C. Similarly, pick-up and drop-out voltages will be higher than indicated at temperatures above 25°C and lower than indicated at temperatures below 25°C.
- 7. For pick-up testing of contactors with dual coils, the voltage can not be ramped up slowly, but must be applied instantly to at least the maximum pick-up voltage. Otherwise, the contactor will not pick-up.
- Limit make current to avoid contact welding. Contact Sensata regarding DC Power Switching Cycle Life for part numbers that include auxiliary contacts.
- 9. Auxillary contact rating is 2A, 24Vdc Resistive load, 100,000 cycles. Minimum current is 0.1mA, 5V. The auxiliary contact is mechanically linked to the main power contacts.
- Contactors feature internal transorb for coil suppression. No external diodes should be added across the coil. The use of additional external coil suppression can slow the release time and invalidate the life cycle ratings, or can cause the contactor not to be able to interrupt the maximum current specified. If lower coil back EMF is required, please contact Sensata for assistance.
- · Applications with capacitors will require a pre-charge circuit.
- Electrical life rating is based on resistive load with 27µH maximum inductance in circuit. Because your application may be different, we suggest you test the contactor in your circuit to verify life is as required.
- End of life is defined as when the dielectric, insulation resistance or contact resistance fails the specifications listed.
- Contact Sensata regarding DC Power Switching Cycle Life for part numbers that include auxiliary contacts.

Page

Sensata Technologies, Inc. ("Sensata") data sheets are solely intended to assist designers ("Buyers") who are developing systems that incorporate Sensata products (also referred to herein as "components"). Buyer understands and agrees that Buyer remains responsible for using its independent analysis, valuation, and judgment in designing Buyer's systems and products. Sensata data sheets have been created using standard laboratory conditions and engineering practices. Sensata has not conducted any testing other than that specifically described in the published documentation for a particular data sheet. Sensata may make corrections, enhancements, improvements, and other changes to its data sheets or components without notice.

Buyers are authorized to use Sensata data sheets with the Sensata component(s) identified in each particular data sheet. HOWEVER, NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OTHERWISE TO ANY OTHER SENSATA INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY THIRD PARTY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT, IS GRANTED HEREIN. SENSATA DATA SHEETS ARE PROVIDED "AS IS". SENSATA MAKES NO WARRANTIES OR REPRESENTATIONS WITH REGARD TO THE DATA SHEETS OR USE OF THE DATA SHEETS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING ACCURACY OR COMPLETENESS. SENSATA DISCLAIMS ANY WARRANTY OF TITLE AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, QUIET ENJOYMENT, QUIET POSSESSION, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS WITH REGARD TO SENSATA DATA SHEETS OR USE THEREOF.

All products are sold subject to Sensata's terms and conditions of sale supplied at www.sensata.com SENSATA ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR THE DESIGN OF BUYERS' PRODUCTS. BUYER ACKNOWLEDGES AND AGREES THAT IT IS SOLELY RESPONSIBLE FOR COMPLIANCE WITH ALL LEGAL, REGULATORY, AND SAFETY-ELATED REQUIREMENTS CONCERNING ITS PRODUCTS, AND ANY USE OF SENSATA COMPONENTS IN ITS APPLICATIONS, NOTWITHSTANDING ANY APPLICATIONS-RELATED INFORMATION OR SUPPORT THAT MAY BE PROVIDED BY SENSATA.

**MACINE Address: Sensata Technologies, Inc. 670 Pleasest Street Additions MACING USE AND ACTIONS AND ACTION

Mailing Address: Sensata Technologies, Inc., 529 Pleasant Street, Attleboro, MA 02703, USA

CONTACT US

Americas +1 (805) 684-8401 gigavac@sensata.com